

POSIFLEX CD 2860 QUICKPOS SETUP



%\$/2

**SET ALL DEFAULT
PAGE 12**



%\$/3

**START CONFIGURATION
PAGE 12**



%7S0+

**CR TERMINATOR
PAGE 19**



%500+

**1ST SET
PAGE 62**



%51S+

**ALL CODE
PAGE 64**



1

**1
PAGE 65**



%520+

**CHARACTER POSITION TO BE INSERTED
PAGE 64**



7E

**~
PAGE 69**



%530+

**CHARACTER TO BE INSERTED COMPLETE
PAGE 64**



%\$/4

**END CONFIGURATION
PAGE 12**



%\$/0

**SAVE PARAMETERS
PAGE 12**