

POSIFLEX CD3830 QUICKPOS SETUP



\$%+PRO

PROGRAM PAGE 90



!IN

DEFAULT VALUE INITIALIZATION PAGE 91



\$%+PRO

PROGRAM PAGE 78



8AA

PREFIX CHARACTER SETTING PAGE 78



/7

7 INSIDE BACK COVER



/E

E INSIDE BACK COVER



% %

FINISH INSIDE BACK COVER



%\$\$

EXIT PAGE 79